



POLY FILLER INSTRUCTIONS

A PERFECT MATCH EVERY TIME



VETERAN OWNED COMPANY

Marine Coat One

1177 N. Red Gum St., Anaheim, CA 92806

Office: (888) 370-9455 / Email: info@marinecoatone.com

A subsidiary of Multi-Tech Products



POLY FILLER

PROFESSIONAL REPAIR IN 3 EASY STEPS

1. Prepare the chip, gouge or crack by using a grinding tool, putty knife, razor knife or other sharp tool. Be sure to create a "V" shape going through the depth of the surface (color) stopping at the fiberglass structure - 1/16" to 3/16" deep. Remove all loose particles and clean the area with acetone or nail polish remover.
2. Dispense a desired amount of Poly Filler into the mixing cup. Add 3% to 5% cream hardener to the Poly Filler and mix thoroughly using the provided stir stick. Then apply mixture to the repair area. Be sure to over fill the crack or chip slightly. The mixed material must be used within 5 minutes.
3. Wet sand so that the contour of the repair matches the surrounding area starting with the 100 grit and finishing with the 320 grit.

Additional Instructions:

Damage Preparation: A Dremel type tool can be used to grind the damaged area ready for Poly Filler.

Sanding: For best results wet sand (with wet/dry sandpaper and water) 100, 220 and 320 grit sandpaper.

Safety: Use proper ventilation. Avoid contact with skin and eyes.